JANOME

Servo Press JP Series 4 Head / Stand Alone Type

How to Read the Model No. / Serial No.

Plate is affixed to press unit.

Identification Plate Positions



How to Check the Identification Plate



① Model Number

② Serial Number

Example: 08－10N0001